


EUREKA®

Hand Held Vacuum Cleaner Household Type Owner's Guide Model 50 Hand Vac



Index

Important Safeguards	2
Service Information	4
Identify Parts	5
Assembly	6
How to Use	7
Trouble Shooting	8
Customer Order Form	9
Warranty	11

For location of nearest
Eureka Warranty Station
or Service Information call
1-800-282-2886*.

*En Mexico llame al 5670-6169

www.eureka.com

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS VACUUM CLEANER.

WARNING

To reduce the risk of fire, electric shock or injury:

- Do not use outdoors or on wet surfaces.
- **Do not leave vacuum cleaner when plugged in.** Turn off the switch and unplug the electrical cord when not in use and before servicing.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If vacuum cleaner is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center before using.
- Do not pull or carry by cord, use cord as a handle, close door on cord, or pull cord around sharp edges or corners. Do not run vacuum cleaner over cord. Keep cord away from heated surfaces.
- Do not use extension cords or outlets with inadequate current carrying capacity.
- Turn off all controls before unplugging.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- This vacuum cleaner creates suction. Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without motor filter in place.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.
- Store your cleaner indoors in a cool, dry area.
- Keep your work area well lighted.
- Unplug electrical appliances before vacuuming them.

SAVE THESE INSTRUCTIONS

CONSEILS DE SÉCURITÉ

Lors de l'utilisation d'un appareil électrique, quelques précautions élémentaires doivent être observées, incluant les suivantes:

LISEZ TOUTES LES INSTRUCTIONS AVANT D'UTILISER VOTRE ASPIRATEUR.

AVERTISSEMENT

Pour réduire le risque de feu, de choc électrique, ou de blessure:

- N'utiliser à l'extérieur où sur une surface mouillée.
- **Ne quitté pas l'aspirateur lorsqu'il est branché.** Fermer le poste et débrancher la corde électrique lorsqu'il n'est pas en marche et/ou avant de le réparer.
- N'utilisez pas comme un jouet. Portez attention l'orsque vous l'utilisez pies où par un enfant.
- Utilisez seulement comme décrit dans ce livet. Utilisez seulement les accessoires recommandés par le fabricant.
- N'utilisez pas avec une corde où prise endommagée. Si l'aspirateur ne fonctionne pas comme il le faut, s'y il a été échappé, endommagé, laissé à l'extérieur, où échappé dans l'eau, retourné l'aspirateur à un centre de réparation avant de s'en servir.
- Ne tirez pas et ne portez pas par le corde, utilisez la corde comme une poignée, fermez un porte sur la corde, où tirez la corde autour des coins aign. Ne passez pas l'aspirateur sur la corde. Éloignez la corde des surfaces chaudes.
- N'utilisez pas la corde électrique où la prise de courant avec insuffisamment de capacité de courant.
- Fermez tout les contrôle avant de débrancher.
- Ne pas débrancher en tirant sur le cordon. Pour débrancher, tenez la fiche et non le cordon.
- Ne touchez pas la prise où l'aspirateur avec les mains mouillées.
- Ne mettez aucun objets dans les ouvertures. N'utilisez pas avec des ouvertures bouchés; gardez libre de poussière, tissu ouaté, cheveux et n'importe quoi qui peut réduire la courant atmosphérique.
- Cet aspirateur crée de la succion et contient. Tenir les parties mobiles et les ouvertures loin des cheveux, des habits, des doigts et de toute partie du corps.
- Ne ramassez rien qui brûle où fument, tel que cigarettes, allumettes, où des cendres chaudes.
- N'utilisez pas sans le sac de poussière et filtre(s) en place.
- Utilisez des précautions lorsque vous nettoyé sur des escaliers.
- N'utilisez pas pour ramasser des liquides inflammable où combustible, tel que de l'essence, où utilisé dans les endroits où ses derniers peuvent être présent.
- Entrepousez votre aspirateur à l'intérieur dans un endroit propre et sec.
- Garder votre lieu de travail bun éclairé.
- Débrancher les appareils électrique avant de les balayer.

CONSERVEZ CES INSTRUCTIONS

To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

Afin de réduire le risque de choc électrique, cet appareil est muni d'une fiche polarisée (une des lames est plus large). Cette fiche ne peut être insérée dans une prise polarisée que d'une seule façon. Si la fiche ne peut être insérée dans la prise, retourner la fiche. Si la fiche ne peut toujours pas être insérée dans la prise, faire installer une prise adéquate par un électricien qualifié. Ne pas modifier la fiche.

GENERAL INFORMATION

The cleaner is designed to pick up dirt and dust particles. Avoid picking up hard or sharp objects that could damage the vacuum cleaner.

Service Information

The instructions in this booklet serve as a guide to routine maintenance. For additional service information telephone our toll free number for the nearest Eureka Authorized Warranty Station. **You should know the model, type and serial numbers when you call:**

USA: 1-800-282-2886

México: 5670-6169

Canada: 1-800-282-2886

If you prefer, you can write to The Eureka Company, Service Division, 807 North Main Street, Bloomington, Illinois 61701, USA. In Canada write to The Eureka Company, 866 Langs Drive, Cambridge, Ontario N3H 2N7. Refer to The Eureka Limited Warranty for complete service information.



DO NOT OIL the motor at any time. The bearings are permanently lubricated and sealed.

Rating Plate

The rating plate on the bottom of the cleaner shows the model number. For prompt and complete service information, always refer to these numbers.

THE EUREKA COMPANY
BLOOMINGTON, ILLINOIS 61701 USA
HOUSEHOLD TYPE


MODEL

Model & Type_____

Serial No._____

Identify Parts


- 1. On/Off Power Switch
- 2. Dust Cup Release Button
- 3. Dust Cup
- 4. Handle
- 5. Carrying Strap Connections
- 6. Flexible Hose
- 7. Cleaning Brush
- 8. Crevice Brush
- 9. Carrying Strap
- 10. Dust Cup Filter (inside dust cup)




Assembly

CAUTION: Always unplug from electrical outlet before opening the dust cup.


NOTE: Dust cup filter must be used when operating the hand vac.



1. To open the dust cup, push release button and pull dust cup away from cleaner. Verify that the dust cup filter is inside, then attach the dust cup to the hand vac.



2. To attach the cleaning brush or crevice brush to the hand vac, push brush into the suction hole, as shown.



3. To use the flexible hose, push the end of the hose into the suction hole, then attach the desired brush to the other end of the flexible hose, as shown. Only one end of the hose fits into the hand vac.

To use the carrying strap attach the strap to the connections on the hand vac.

How To Operate Your Hand Vac


CAUTION: The hand vac is a very powerful unit. Make sure that you hold it firmly, otherwise it can slip out of your hand and cause injury.

1. Hold the hand vac firmly with your hand on handle.
2. Push the On (-) Off (0) power switch to "On (-)" position.
3. Start vacuuming.

Changing And Cleaning The Dust Cup Filter

CAUTION: Always unplug from electrical outlet before opening the dust cup.

1. To open the dust cup, push release button and pull off the dust cup.
2. Pull out the dust cup filter (Fig. 2).
3. Empty the dust from the dust cup and shake filter.
4. Occasionally rinse the dust cup filter in cold water. Then wait until it dries completely before replacing it into the dust cup.
5. Place the dust cup filter firmly into the dust cup.
6. Attach the dust cup to the hand vac.



CAUTION: Adequate airflow must be maintained at all times through the cleaner. Any obstructions will cause the motor to overheat resulting in permanent damage.

Trouble Shooting Guide

PROBLEM	POSSIBLE REASON	POSSIBLE SOLUTION
Hand vac will not operate.	<ol style="list-style-type: none">1. Power cord not firmly plugged into outlet.2. No power in wall outlet.	<ol style="list-style-type: none">1. Plug unit in firmly.2. Check fuse or breaker. Replace fuse/reset breaker.
Hand vac will not pickup or suction power is weak.	<ol style="list-style-type: none">1. Dust cup is full.2. Unit clogged.3. Dust cup filter needs cleaning.	<ol style="list-style-type: none">1. Empty dust cup.2. Turn unit off and unplug from wall outlet and check for object(s) causing clog and remove.3. Clean or replace the dust cup filter.
Dust escaping from hand vac.	<ol style="list-style-type: none">1. Dust cup filter needs cleaning.2. Dust cup filter is not installed correctly.3. Puncture/hole in dust cup filter.	<ol style="list-style-type: none">1. Empty dust cup and clean filter.2. Review dust cup filter instructions.3. Replace dust cup filter.
Hand vac hose or brushes will not pickup.	<ol style="list-style-type: none">1. Hose clogged.2. Dust cup is full.	<ol style="list-style-type: none">1. Remove hose and/or brushes. Remove obstruction from hose.2. Empty and clean dust cup and clean dust cup filter.

S O L D T O

Name		
Address (street address needed for UPS)		
City	State	Zip
Telephone (Day)	(Eve)	(Fax)

S H I P T O

Name		
Address (street address needed for UPS)		
City	State	Zip
Telephone (Day)	(Eve)	(Fax)

To Order




By Phone
1-800-
438-7352*

HOURS:
Call between 8 a.m.
and 4:45 p.m.
central standard time
Monday through Friday.

By FAX

1-309-823-5789
*En Mexico
llame al 5670-6169

By Mail



Simply fill out this
Order Form.
Please be sure to
include day
and evening
phone numbers.

www.eureka.com

71891






Model Number _____

Type _____

Serial Number _____

IMPORTANT:

Be sure to include
your model, type, and
serial numbers. These
numbers may be
found on the rating
plate.

Genuine Eureka Parts				Part No.	Qty.	Price (USD)	Total
	Filter Assembly			61811		1.99	
	Hose Assembly			61808		4.99	
	Large Brush			61809		1.99	
	Small Brush			61810		1.79	
	Strap			61812		2.99	
To Answer Problems or Questions for U.S.A. and Canada call: 1-800-282-2886* 7 a.m. to 8 p.m. central standard time Monday through Saturday				Total (prices subject to change without notice)			
				Tax (add state and local taxes as required by law)			
				Postage and Handling Charge (Within the U.S.A.)			\$3.75
				TOTAL			

Method of Payment (No C.O.D.s)

☐ Check or money order (payable to The Eureka Company). Do not send currency.

☐ Charge to my ☐ Visa (13/16 digits) ☐ MasterCard (13 digits) ☐ American Express (15 digits)

Acct. number

Expiration date

Signature (Full name as shown on account) _____

THE EUREKA LIMITED WARRANTY

What This Warranty Covers

Your Eureka cleaner is warranted to be free from all defects in material and workmanship in normal household use for a period of one year. The warranty is granted only to the original purchaser and members of his or her immediate household. The warranty is subject to the following provisions.

What This Warranty Does Not Cover

- Parts of the cleaner that require replacement under normal use, such as disposable dust bags, filters, drive belts, light bulbs, and brush roll bristles
- Damages or malfunctions caused by negligence, abuse, or use not in accordance with the Owner's Guide.
- Defects or damages caused by unauthorized service or the use of other than Genuine Eureka parts.

What The Eureka Company Will Do

The Eureka Company will, at its option, repair or replace a defective cleaner or cleaner part that is covered by this warranty. As a matter of warranty policy, the Eureka Company will not refund the consumer's purchase price.

Warranty Registration

Please fill out and return the warranty registration card accompanying your cleaner.

Obtaining Warranty Service

To obtain warranty service you must return the defective cleaner or cleaner part along with proof of purchase to any Eureka Authorized Warranty Station. You will find the nearest location in the Yellow Pages, under "Vacuum Cleaners—Service and Repair." Be certain that the Warranty Station is "Eureka Authorized." For the location of the nearest Eureka Authorized Warranty Station or for service information, telephone toll free:

USA: 1-800-282-2886

Mexico: 5670-6169

Canada: 1-800-282-2886

If you prefer, you can write to The Eureka Company, Service Division, 807 North Main Street, Bloomington, Illinois 61701, USA. In Canada write to The Eureka Company, 866 Langs Drive, Cambridge, Ontario N3H 2N7.

If it is necessary to ship the cleaner outside your community to obtain warranty repair, you must pay the shipping charges to the Eureka Authorized Warranty Station. Return shipping charges will be paid by the Warranty Station. When returning parts for repair, please include the model, type, and serial numbers from the data plate on the cleaner.

Further Limitations and Exclusions

Any warranty that may be implied in connection with your purchase or use of the cleaner, including any warranty of Merchantability or any warranty for Fitness For A Particular Purpose is limited to the duration of this warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

Your relief for the breach of this warranty is limited to the relief expressly provided above. In no event shall Eureka be liable for any consequential or incidental damages you may incur in connection with your purchase or use of the cleaner. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary by state.



Questions & Answers about Genuine Eureka Products

Q: Why should I use only Genuine Eureka paper bags, belts, and parts in my Eureka vacuum cleaner?

A: Using Genuine Eureka Products, which are made to our exacting specifications and engineered with emphasis on quality, performance, and customer satisfaction, ensures the long life and cleaning efficiency of your vacuum cleaner. Overall, this saves you money and helps to keep your home clean.

Q: How can I be sure I am using only genuine Eureka products in my vacuum cleaner?

A: Typically, packaged products and paper bags can be identified by a "Genuine Eureka Product" symbol (see illustration above). For further identification assistance, you may call our toll-free number, 1-800-282-2886, for the location of a nearby Eureka Authorized Warranty Station.

Q: Are there any differences between "made to fit" or "imitation" and Genuine Eureka paper bags, belts, and parts?

A: Yes, there are some very important differences in materials, quality, and reliability. Many customers have mistakenly purchased "imitation" paper bags and parts while thinking they purchased genuine. Unfortunately, many of these customers discovered the differences after they experienced related difficulties.

For Genuine Eureka Value, Accept No Limitations!
THE EUREKA COMPANY

Household Warranty
abs 190